

ENVIROALERT EA400

This EA400 illustration depicts:

12V power pulled from security panel

Normally Open (N.O.) wiring

Zone 1 - Temperature sensing

Zone 2 - Water sensing using W-S-U

Console will alarm if lead is cut

Zone 3 - Open for future application

Zone 4 - Open for future application

BZ-1 external alarm notification

Please note:

Sensors and BZ-1 sold separately.

Wire is not included with EA400.

We recommend 22 AWG twisted pair.

